

LUPA HF

Cold light luminaire with magnifying lens, essential for high precision work. Its use is ideal for hospitals, medical centers, laboratories and aesthetic clinics.

Light Source

Low consumption 22W circular fluorescent tube.

Produces a light without shadows and does not heat.

Lifetime of 10.000 hours.

Functionality and performances

Adjustable height articulated arm that allows easy adjustment in different positions.

Head with biconvex circular lens of 5 diopters, adjustable and simple mechanism.

Switch on the head of the luminaire.

Security and hygiene

Protective cover on the head to prevent dust or rub that may damage the lens.

Mounting Options

Standard version includes AH table clamp.

As accessories, we offer a wide selection of supports such as wall clamps, wall extension arm and trolley stand.



LUPA HF

Technical Details (Cod. 09332)	
Light source	FL 22W
Lamp lifetime	10.000 hours
Colour temperature	6.500 °K
Glass lens	5 diopters
Lens diameter	125 mm
Arm length	90 cm
Weight	3 kg
Colour	White

Trolley stand
8,8 kg Cod. 09651





Wall support
Cod. B0101800



AH table clamp
Cod. B010190



Rail Plus bracket
Cod. 82026



Extension wall arm
Cod. B0101S0

Fixing lock

Switch on the head



Safety lid

Hinge mechanism



Circular fluorescent

Circular glass lens

